



SWISS DIAMOND

Assembly Instruction for aerator/fan knob

Knob of the cover



Steam-lock




Ring to protect fingers



Cover



Pane which has to be put under



Screw



5. ↓ 1. Lead screw through the opening/aperture of the pane which has to be put under.
3. ↓ 2. Lead screw with the pane on the inner surface of the glass-pane through the aperture and hold tight.
4. ↓ 3. Insert steam-lock in the ring which protects the fingers as shown in the figure. Wings and pin must form a line. Only in this position the steam-lock is "slits" in the right way.
2. ↑ 4. Put ring which protects the finger with inserted steam-lock on the top side of the glass pane. The screw must be visible!
1. ↑ 5. Put knob of the cover on the ring, which protects the fingers, and tighten the bolt with a clockwise (to the right) with the screw.

Caution: Assemble screw only fingertight